



# Introduction to Industrial Robot Programming

Sarper ALKAN

sarper@cankaya.edu.tr

# What is an industrial robot?

- Designed for:
  - High movement precision
  - High speed
  - High repeatability
- Easy to program
- High safety
- Low maintenance costs
- Flexible



# Our robot: Stäubli TX90XL


- 6 axis articulated robot arm
- High-speed, high-resolution servo motors with absolute position sensors at each axis
- Nominal payload: 5 *kg*
- Repeatability:  $\pm 0.04$  *mm*
- Weight: 116 *kg*
- Arm reach: 1.5 *m*

# Our robot: Stäubli TX90XL



Manual control:  
Pendant

Cabinet




Robot arm

# Pendant



# Safety

- Always operate the robot arm at low speed (%10 speed) at first
- Be ready to stop arm motion:
  - Emergency stop (the big red button),
  - Arm power off,
  - Move/hold key,
  - Dead man's switch.




# Safety

- Do not use the robot pendant without supervision.
- Do not run your program without supervision.



# Pendant operations






# Manual movement

- Joint move: Moves the robot by rotating the individual joints
  - Cannot do linear movement
  - Is not subject to singularity
- Frame move: Moves the robot in a specified coordinate frame
  - Can do linear movement
  - Subject to singularity
- Tool move: Moves the robot with respect to the tool coordinate frame
  - Can do linear movement
  - Subject to singularity

# Manual movement with the joint move



1 Joint




2 Speed

- +



- +

3



! Requested !

-JT1


-JT2

-JT3



-JT4

-JT5

-JT6





# Manual movement with the frame move: Coordinate system



**!! Right Hand !!**

**3 axis perpendicular each other**


# Manual movement with the frame move: Translation



② Speed




① Frame



! Requested !





T  
r  
a  
n  
s  
l  
a  
t  
i  
o  
n



# Manual movement with the frame move: Rotation



Screw



Unscrew






Rotation




# Manual movement with the tool frame: Coordinates


ROBOTICS  
MAN AND MACHINE




# Manual movement with the tool frame:



! Requested !




Translation





# Creating applications with VAL3:

- Need:
  - VAL3 installed
  - A 'cell' defined (controller, robot, tool)
  - Licence (licence flash-disk attached to the computer)




Click here for new application

The 'New Application' dialog box is shown, with a red arrow pointing to the 'Name' field. The 'Name' field contains the text 'DeneyGrup1'. The 'Location' field is set to 'Disk:/' and the 'Template' field is set to 'default'. The 'OK' and 'Cancel' buttons are at the bottom right.

|           |            |
|-----------|------------|
| Name:     | DeneyGrup1 |
| Location: | Disk:/'    |
| Template: | default    |

Name your application:  
DeneyGrup(your group  
number)



View



DeneyGrup1-start\* X



Ex1-start

```
1 begin
2     movej (jStart,tTool,mNomSpeed)
3     movej (appro (p1, trAAppl), tTool,mNomSpeed)
4     movel (p1,tTool,mNomSpeed)
5     movel (p2,tTool,mNomSpeed)
6     movel (p3,tTool,mNomSpeed)
7     movel (p4,tTool,mNomSpeed)
8     movel (p5,tTool,mNomSpeed)
9     movel (p6,tTool,mNomSpeed)
10    movel (p7,tTool,mNomSpeed)
11    movel (p8,tTool,mNomSpeed)
12    movel (p9,tTool,mNomSpeed)
13    movel (p10,tTool,mNomSpeed)
14    movel (p1,tTool,mNomSpeed)
15    movej (appro (p1, trAAppl), tTool,mNomSpeed)
16    movej (jStart,tTool,mNomSpeed)
17    waitEndMove ()
18 end
```

FUNCTIONS

VARIABLES

# Applications: Structure

- Variable types:
  - **pointRx**: a point location in cartesian coordinates ( $p_1, p_2, p_3, \dots$ )
  - **jointRx**: a joint location in joint coordinates ( $jStart$ )
  - **tool**: a tool defined by the user ( $tTool$ )
  - **trsf**: a transformation ( $trAApl$ )
  - **mdesc**: motion descriptor ( $mNomSpeed$ )

# Applications: Structure

- Functions:
  - `movej(joint, tool, mdesc)`: move to a (point or joint) coordinate with specified tool and motion descriptor
  - `movel(point, tool, mdesc)`: move linearly a point coordinate with specified tool and motion descriptor
  - `appro(point, trsf)`: calculate a transformed point by using a point and a transformation
  - `waitEndMove`: wait for the current movement to end.


# Movement with movej

**MOVEMENT : MOVEJ**

`Movej(point,tool,mdesc)`

or

`Movej(joint,tool,mdesc)`



Joint Interpolation : curved movement

Speed and acceleration described by motion descriptor

No problem of singularity crossing

Motion to use if no constraint : Obstacle, insertion, . . .




# Movement with move

## MOVEMENT : MOVE

Move(point,tool,mdesc)

Not available on JOINT



Cartesian Interpolation : straight line movement

Speed and acceleration described by motion descriptor

Problem of singularity crossing => slow down

Motion to use in case of constraint : obstacle, insertion, process,

...

# Motion descriptor parameters: blend


## SMOOTHING : BLENDING

MAN AND MACHINE

```
+flange
+world
+jo mFast
-md Speed (%) : 100
m
m Blend : Joint
bo
nu
string
aio
```

Vel : % of nominal speed of joints

No blending : OFF  
Blending activated : JOINT



# Example program:

View

1 **begin**

2     movej (jStart, tTool, mNomSpeed)

Move to the starting location

3     movej (appro (p1, trAAppl), tTool, mNomSpeed)

Approach to point 1

4     movel (p1, tTool, mNomSpeed)

Move to point 1

5     movel (p2, tTool, mNomSpeed)

Move to point 2

6     movel (p3, tTool, mNomSpeed)

7     movel (p4, tTool, mNomSpeed)

8     movel (p5, tTool, mNomSpeed)

9     movel (p6, tTool, mNomSpeed)

- Use as many points
- as necessary

10    movel (p7, tTool, mNomSpeed)

11    movel (p8, tTool, mNomSpeed)

12    movel (p9, tTool, mNomSpeed)

13    movel (p10, tTool, mNomSpeed)

Move to point 10

14    movel (p1, tTool, mNomSpeed)

Move to point 1

15    movej (appro (p1, trAAppl), tTool, mNomSpeed)

Approach to point 1

16    movej (jStart, tTool, mNomSpeed)

Move to the starting location


17    waitEndMove ()

Wait for the movement to end

18 **end**

# Adding variable definitions:

```
begin
  movej (jStart, tTool, mNomSpeed)
  movej (appro (p1, trAAppl), tTool, mNomSpeed)
  movej (p1, tTool, mNomSpeed)
  movej (p2, tTool, mNomSpeed)
  movej (p1, tTool, mNomSpeed)
  movej (p2, tTool, mNomSpeed)
  movej (p1, tTool, mNomSpeed)
  movej (p2, tTool, mNomSpeed)
  movej (p1, tTool, mNomSpeed)
  movej (p2, tTool, mNomSpeed)
  movej (p1, tTool, mNomSpeed)
  movej (p2, tTool, mNomSpeed)
  movej (p1, tTool, mNomSpeed)
  movej (p2, tTool, mNomSpeed)
  movej (p1, tTool, mNomSpeed)
  movej (p2, tTool, mNomSpeed)
  waitEnd
end
```



Right click on the variable to add (p2), select add, new data

# Adding variable definitions:

```
begin
  movej (jStart, tTool, mNomSpeed)
  movej (appro (p1, trAAppl), tTool, mNomSpeed)
  movel (p1, tTool, mNomSpeed)
  movel (p2, tTool, mNomSpeed)
  movel (p3, tTool, mNomSpeed)
  movel (p4, tTool, mNomSpeed)
  movel (p5, tTool, mNomSpeed)
  movel (p6, tTool, mNomSpeed)
  movel (p7, tTool, mNomSpeed)
  movel (p8, tTool, mNomSpeed)
  movel (p9, tTool, mNomSpeed)
  movel (p10, tTool, mNomSpeed)
  movel (p1, tTool, mNomSpeed)
  movej (appro (p1, trAAppl), tTool, mNomSpeed)
  movej (jStart, tTool, mNomSpeed)
  waitEndMove ()
end
```

Select the appropriate variable type from the list

Add New Data (DeneyGrup1.pjx)

Types:

Stäubli Types

- aiio
- frame
- pointRs
- tool
- bool
- jointRs
- pointRx
- trsf
- configRs
- jointRx
- screen
- configRx
- mdesc
- sio
- dio
- 3/4 num
- Ab string

Container:

- StrArray
- StrCollection

Properties

Name: p2

Access: ☐ Public

Size(s): 1


Enter the size of each dimensions, separated with a comma (3 or 2,3 or 2,3,2)

OK Cancel

# Editing mdesc and trsf

Right click on a variable and select 'Go to definition' to edit the variable. Edit only mdesc and trsf this way.


- mdesc: mNomSpeed



The screenshot shows a software interface with a table titled 'Ex1 Data-mNomSpeed'. The table has 9 columns: Index, accel, vel, decel, tvel, rvel, blend, leave, and reach. The first row contains the values 0, 100, 100, 100, 99999, 99999, joint, 10, and 10.

| Index | accel | vel | decel | tvel  | rvel  | blend | leave | reach |
|-------|-------|-----|-------|-------|-------|-------|-------|-------|
| 0     | 100   | 100 | 100   | 99999 | 99999 | joint | 10    | 10    |


- trsf: trAApl



The screenshot shows a software interface with a table titled 'Ex1 Data-trAApl'. The table has 7 columns: Index, x, y, z, rx, ry, and rz. The first row contains the values 0, 0, 0, -100, 0, 0, and 0.

| Index | x | y | z    | rx | ry | rz |
|-------|---|---|------|----|----|----|
| 0     | 0 | 0 | -100 | 0  | 0  | 0  |

# Applications: using pendant






# Applications: Teaching with pendant

## TOOL SELECTION

MAN AND MACHINE




75%

—Jog Interface—  
Tool:flange  
Frame:world  
Step:Off

|     |   |     |   |     |   |
|-----|---|-----|---|-----|---|
| J1: | 0 | J2: | 0 | J3: | 0 |
| J4: | 0 | J5: | 0 | J6: | 0 |

—Point— —Joint—

New Par. Sel.



75%

—Jog Interface—  
Tool:(test) flange  
Frame:(test) world  
—Select Tool—  
-Val3 applications  
-test  
+flange

New Save Esc Ok

75%


—Jog Interface—  
Tool:(test) flange  
Frame:(test) world  
—Select Tool—  
-Val3 applications  
-test  
-flange  
tGripper

Edit Ren. Del. New Esc Ok



# Applications: Teaching with pendant



## TOOL EDITION



Teach locations

Position and speed control

Geometrical adjustments





- Geometrical Definition
- Associated digital output
- Delay to open / close in secs.

# Applications: Teaching with pendant






Move to the desired position by using the manual control



# Applications: Teaching with pendant



Move to the desired position by using the manual control



# Elements of the jog interface

## JOG INTERFACE

MAN AND MACHINE

### Points of an application

Symbols in front of points name :

VAL3 6.5+

0 : Point not taught, coordinates = 0

@ : Robot at position with current tool (approx 0.01 mm)

~ : Robot close to position (approx. 1 mm)

! : Position not reachable with current tool

0.5%

Jog Interface

Tool:(exercise) tGripper

Frame:(exercise) world

Step:On/1

|     |   |     |      |     |   |
|-----|---|-----|------|-----|---|
| J1: | 0 | J2: | 0    | J3: | 0 |
| J4: | 0 | J5: | 0.09 | J6: | 0 |

| Point      | Joint    |
|------------|----------|
| ! pControl | jSafe    |
| ~ pPick    | @ jStart |
| 0 pPlace   |          |

Here Ins. Del. Save New Par. Sel.

Teach current position

Insert point  
In an array

New  
point

Save current application (select by the tool)

delete point (check if not used) or array element

Select tool or frame

Parameters step mode

# Re-teaching an existing point:

## POINTS RE-TEACHING

- Possible to verify / re-teach points : POINT mode



- 1 movement type = Mode : JOINT
- 2 with/without APPRO : direction selection + distance

```
0.5%
---Jog Interface---
Tool:(exercise) tGripper
Frame:(exercise) world
Mode:JOINT Appro:Off


J1:  0   J2:  0   J3:  0
J4:  0   J5:  0.09 J6:  0

Point-----Joint-----
! pControl      jSafe
~ pPick         @ jStart
0 pPlace


Here Ins. Del. Save New Par. Mode Sel.
```



**motion Control**



tool select






# Re-teaching an existing point:

## POINTS RE-TEACHING


- Possible to verify / re-teach points : POINT mode



- 1 movement type = Mode : LINE
- 2 with/without APPRO : direction selection + distance



motion Control




tool select




# Re-teaching an existing point:

## POINTS RE-TEACHING

Verify / re-teach points : APPRO mode



Editable values



**motion Control**

- Shortcuts : APPRO ON/OFF = F6 + F6

# Re-teaching an existing point:


## RE TEACHING : ALIGN




Possible to verify / re-teach points : POINT mode

- 3 move Type = Mode : **ALIGN** (related to current frame)

Align Z of the TOOL Z on the closest axis of current frame.




**motion Control**



# Running applications:

Running application

3



2

OK : Validation



4

Enable  
Movement

1

Start

# Running applications: Slow running



Cell opened

2

Motion when  
keep pressed



Speed adj.

1

Remove current selected  
mode = press button

# Create your own application:

- Get together with a group of 3-4 people (no less than 3 no more than 4)
- Get an appointment from Mr.Volkan Erbay (robotics lab technician) **!!do this as soon as possible!!**
- Create an application, teach the points, and write a letter of 'MEKATRONİK' by using your application
- Almost everything that you need to create and run the application are in these slides
- **You need to complete this assignment in 2 weeks from now.**